


TOM & BASS DRUM CASES

CASE	A	A / FOAM	B	B / FOAM	C'	D	E
8" Tom Case	9.50	9.00	11.25	10.75	10.00	10.00	4.50
10" Tom Case	11.50	11.00	13.50	13.00	12.00	11.50	4.50
12" Tom Case	13.25	12.75	13.75	13.25	14.00	12.25	4.50
13" Tom Case	14.75	14.25	17.75	17.25	15.25	12.00	4.50
14" Tom Case	15.50	15.00	18.25	17.75	16.00	13.00	4.50
15" Tom Case	16.00	15.50	19.50	19.00	17.00	16.25	5.00
16" Tom Case	17.00	16.50	21.00	20.50	18.00	19.00	5.00
18" Tom Case	19.50	19.00	22.75	22.25	19.50	19.00	5.00
18" Marching Bass Case	19.50	19.00	22.75	22.25	19.50	17.50	5.00
18" Bass Case	21.00	20.50	25.50	25.00	22.00	20.00	5.00
20" Marching Bass Case	21.00	20.50	25.50	25.00	22.00	20.25	5.00
20" Bass Case	22.50	22.00	27.00	26.50	23.50	21.00	5.00
20" Extended Bass Case	22.50	22.00	27.00	26.50	23.50	25.00	5.00
22" Bass Case	25.00	24.50	29.50	29.00	26.00	21.00	5.00
22" Extended Bass Case	25.00	24.50	29.50	29.00	26.00	26.00	5.00
24" Bass Case	27.00	26.50	33.00	32.50	28.00	21.00	5.00
24" Extended Bass Case	27.00	26.50	33.00	32.50	28.00	26.75	5.00
26" Bass Case	29.00	28.50	34.50	34.00	28.50	21.25	5.00
28" Bass Case	30.25	29.75	36.50	36.00	31.00	19.50	5.00
30" Bass Case	31.75	31.25	39.50	39.00	32.50	21.00	5.00
32" Bass Case	40.75	40.25	40.75	40.25	35.00	20.50	5.00



SNARE & TIMBALE CASES

CASE	A	A / FOAM	B	B / FOAM	C'	D	E
3", 4", 5" x 14" Snare	16.00	15.50	21.00	20.50	16.00	7.50	6.00
6.5" x 14" Snare Case	16.00	15.50	21.00	20.50	16.00	7.50	6.00
8" x 14" Snare Case	16.00	15.50	21.00	20.50	16.00	8.50	7.50
14" Timbale Case	17.00	16.50	22.50	22.00	17.00	14.25	5.75
15" Timbale Case	17.00	16.50	22.50	22.00	17.00	14.25	5.75
14" Marching Snare Case	17.00	16.50	22.50	22.00	17.00	14.25	5.75
15" Marching Snare Case	17.00	16.50	22.50	22.00	17.00	14.25	5.75
Large Marching Snare	19.50	19.00	23.25	22.75	19.50	17.50	5.75

