



www.gatorcases.com

# G-TOUR-LCDLIFT-50P

## Assembly Instructions

### Tools needed:

- Ratchet or nut driver set
- Phillips Screwdriver
- Razor Knife
- Assistant

### Instructions for Unpacking

The G-TOUR-LCDLIFT-50P is packaged on a rugged shipping pallet to protect the casters during shipping.

- 1) Using a razor knife, cut away straps that hold the cardboard cover on the case
- 2) Be careful to cut away from the box as to not pierce the box and damage the exterior of the case.
- 3) The main body of the cardboard will then lift off the case.
- 4) Then the entire case must be lifted off the shipping pallet to free the casters and the case from its packaging.

### Instructions for Mounting

**WARNING!!!!** Do not remove “Lock Block” and or activate the red release mechanism prior to mounting the screen onto the lift.

- 1) Lock wheels for stability during screen mounting
- 2) Remove lid



- 3) Locate mounting hardware in lower left section of case. Hardware is held in case with laptop tray storage straps



- 4) Mount (2) parallel mounting rails to rear of your screen



- 5) With the help of an assistant, lift screen onto the universal mount which is already mounted to the Case Lift Mechanism.



- 7) Tighten restraining bolts on mounting rail to prevent screen from lifting away from universal mount.

- 6) Center screen in desired position

## Operating Instructions

- 1) Remove “Lock Block” by removing lock bolt.
- 2) With left hand, push lift mechanism down 3 to 4 inches by using the “cross bar” handle on the rear of the mount.
- 3) Then while holding mechanism down, press the red release lever and hold it down
- 4) Release the “cross bar” handle
- 5) Once the lift begins to rise, then you may release the red release lever.
- 6) The lift will default to its highest position



- 7) Using the “cross bar” handle, you can adjust the height by pulling the lift downward until a “click” is heard.



For more information on this or any other Gator Cases product go to [www.gatorcases.com](http://www.gatorcases.com)  
or call customer service at 813-221-4191